

CLEANING INSTRUCTIONS / waterless Urimat-urinals

Use only MB ActiveCleaner cleaning fluid for cleaning.

Do not use chemicals or solvents that damage the surface of the urinal.



Dilute the concentrated cleaning fluid.



Lift the grate off the odor trap.



Spray cleaning fluid over the entire urinal.



Wipe the urinal on the outside first.



Then wipe the urinal's inside.



Do not forget the edges of the odor trap and the grate.



Wipe the grate on both sides.



Place the cleaned grate on the odor trap.



Wipe the lower part of the urinal and its surroundings.



Spray a thin layer of MBActiveCleaner into the urinal bowl.

